

## Durallo Splashbacks and Panels Care and Maintenance

### General

Durallo Splashbacks and Panels do not require any special cleaning products. Regular cleaning using a mild detergent and a soft micro-fibre, non-abrasive cloth will ensure your Durallo surface remains in good condition.

Excessive heat from large burners that are not adjusted correctly can damage/scorch the Durallo surface. To avoid this damage ensure you review in details the user guide for your cooktop.

### Regular Care and Maintenance

The surface should be cleaned regularly and ensure that you do not allow food stuffs, cooking oils, fats etc. to build up on the surface. The use of a mild detergent with a micro-fibre cloth is the recommended method to clean the Durallo Splashbacks and Panels Surface.

Avoid cleaning the Durallo surface when hot. Do not clean the surface with cleaning products that are highly caustic or acidic and or abrasive.

### Scratch Prevention

Do not place sharp or metallic cooking and kitchen implements, appliances or items against the Durallo surface.

The use of abrasive cleaners, scotch brite pads, steel wool etc. are to be avoided. Use a micro-fibre cloth and a mild detergent to clean the surface.

### In summary

- **DO** use a soft micro-fibre cloth with a mild detergent
- **DO** clean the surface regularly
- **DO** ensure that your cooktop burners are adjusted to the manufacturers recommendations
- **DO NOT** allow food stuffs to build up on the surface
- **DO NOT** use abrasive cleaners, scotch brite pads, steel wool etc.
- **DO NOT** use cleaning solutions that are highly acidic or caustic
- **DO NOT** clean the surface if it is hot
- **DO NOT** place metallic or sharp implements against the surface, which can cause scratching