

WILSONART DECORATIVE PANELS CARE AND MAINTENANCE

Your Wilsonart Decorative Panels are manufactured from the highest quality materials and designed to provide years of trouble free service in vertical interior applications. Whilst your panels are made from a MR MDF E0 and as with any wood based panel they cannot be made totally waterproof, care should be taken to wipe up spills immediately, ensuring the panels are not exposed to high or continuous levels of moisture, steam and humidity.

General Cleaning

Use warm soapy water (a mild dish washing detergent) via a damp cloth to wipe down the Wilsonart Decorative Panel taking care not to rub too hard. Dry using a lint free soft cloth, ideally a micro fibre cloth, so as not to leave any residue on the panel.

You may also use Methylated Spirit on a soft cloth, using a circular cleaning motion. Thoroughly clean over the wider area with water and detergent on a damp cloth afterwards to remove any residual Methylated Spirit.

The use of Windex and a micro fibre cloth is also an acceptable method of cleaning and will not harm the surface of the product.

Always ensure that you refer to the recommendations provided by any cleaning product manufacturer before use.

To ensure that your Wilsonart Decorative Panel 10 year warranty will not be void DO NOT use any of the following on Wilsonart Decorative Panel:

- Commercial Cleaning Products,
- Abrasive Cleaners,
- Scouring Pads or Abrasive Papers,
- Acids and Alkalis,
- Solvents,
- Thinners,
- Turpentine (Turps),
- Ammonia,
- Bleach,
- Acetone,
- Easy-Off BAM!,
- M.E.K. or any other cleaning agents containing organic solvents or the above mentioned products.

Avoid contact with sharp implements. Should you need help, Please call our toll free number at 1300 854 166.