

Durable. Contemporary. High-quality.

WILSONART LAMINATES

CARE AND MAINTENANCE

Cleaning Tips

To clean the surface, use a damp cloth or sponge and a mild soap or detergent. Difficult stains such as coffee or tea can be removed using a mild household cleaner and baking soda, mixing to achieve a paste consistency. Use a stiff nylon bristle brush, scrubbing (approx. 15-20 strokes) the affected area. Do not heavily scrub the area to avoid damaging or scratching the surface finish.

Stubborn stains that resist any of the above cleaning methods may require the use of nail polish remover. Use a cotton ball saturated with nail polish remover (acetone), and gently rub the stain for up to two minutes. Rinse thoroughly with warm water and wipe dry using a soft cloth. This step may be repeated if the stain appears to be going away and the colour of the laminate has not been affected.

WARNING: Any exposure of the laminate surface to bleach will cause discoloration. Always rinse laminate surfaces after cleaning. Failure to rinse after cleaning can cause damage, even if a small amount of cleaning solution remains on the surface. A dry residue may be invisible however any moisture from cups or drinks can reactivate it, and result in permanently etched scars or stains over time.

Recommended Household Cleaners: Windex Spray Cleaner & Ajax Spray n' Wipe

Caution

- Acidic or abrasive cleaners can damage laminate surfaces; do not use them. Drain cleaners will permanently damage the laminate surface. If you spill a drain cleaner, wipe it up immediately and rinse several times with water.
- Hair, textile and food dyes can cause permanent stains. If dye should happen to spill, wipe it up immediately with dishwashing detergent or an all-purpose cleaner.
- Wipe spills away promptly and rinse several times with water.
- Rust removers contain harsh chemicals, which will quickly cause permanent damage. If a spill occurs, wipe off all residue immediately, wash thoroughly with soapy water and rinse several times.
- Steel wool and other abrasive pads will damage the laminate face. Do not use them for cleaning and don't store steel wool pads on your countertop; the metal can rust and leave stains.
- Toilet bowl cleaners contain harsh chemicals that can cause permanent damage. If spills occur, wipe up immediately, wash surface with soapy water and rinse several times.

Durable. Contemporary. High-quality.

The cleaners listed below can cause damage to the surface of laminate:

Chemical Ingredient	Synonymous Names
Hydrochloric Acid	<i>Muriatic Acid</i> <i>Hydrogen Chloride</i>
Sulfuric Acid	<i>Oleic Acid</i> <i>Oil of Vitriol</i> <i>Oleum</i>
Hydrofluoric Acid	<i>Rust Remover</i>
Phosphoric Acid	<i>Rust Remover</i>
Sodium Hydroxide	<i>Caustic Soda</i> <i>Caustic</i> <i>Lye</i> <i>Soda Lye</i>
Pumice (abrasive)	

Remember, sharp objects can damage the surface of Wilsonart Laminate, lowering wear and stain resistance. Although high pressure laminates are somewhat resistant to scratches, the surface can be damaged, even under normal use.

Should you need help, please call our toll-free number at 1300 854 166.