

Unpacking and Inspecting the Vanity Top

- Inspect all components before installing for any damage that may have occurred during delivery.
- Ensure all components are present based on ordered parts: vanity, sink, and backsplash.

Tools and Protective Items Needed

Silicone (100%)	Caulk	Caulking/Silicone Gun
Clean Shop Towels	Tape Measure	Scotch-Brite™ Finishing Pad 7445 or 7448
Safety Eyewear	Gloves	Protective Footwear

Preparation

- Prepare the installation area by shutting off the water, remove the waterlines and plumbing, and remove the existing vanity.
NOTE: Plumbing should be removed and installed by an experienced plumber.

- Clean the cabinet rails from debris and any other obstructions.
- Make sure the cabinet is level and secure to the wall.

- Measure the new vanity top and compare measurements to cabinet and overhang.

NOTE: Wilsonart[®] THINSCAPE[®] Performance Tops are designed to be delivered and installed without any modifications. If modifications such as cutting, profiling, and/or finishing of edges are required, these can be accomplished by using standard woodworking tooling. Refer to the Wilsonart[®] THINSCAPE[®] Performance Top Fabrication Manual at <https://www.wilsonart.com/thinscape>.

Installation of Vanity Top

- Installation is recommended to be conducted by two people.
- Dry-fit the vanity top to ensure all measurements and components are correct.
- After dry-fitting, secure the vanity top to begin installation of faucet.
- Secure the plumbing fixtures (faucet and drain) according to manufacturer's recommendations.
- Apply a continuous ¼-inch (6mm) bead of 100% silicone along the top of the vanity cabinet rail.
- Secure the vanity top to the backside of the cabinet and/or wall if overhang allows.
- Measure the overhang at the front and sides (if applicable) for equal distance, usually a minimum of ½" overhang.
- Remove any silicone squeeze-out with a clean shop towel, along the cabinet face and/or sides underneath the vanity top.
- Allow 24 to 48 hours for the silicone to cure properly; see manufacturer's recommendations.

Installation of Backsplash

- Dry-fit the backsplash to ensure proper fitting prior to securing to wall.
- Apply a ¼-inch (6mm) silicone bead to the top surface of the vanity top where backsplash will sit.
- Apply a ¼-inch zig-zag bead on the backside of the backsplash.
- Secure the backsplash to the vanity top and wall; hot-melt can be used to hold in place until silicone cures.
- Vertical interactions at side splashes, between backsplash, require a bead of silicone as well.
- Remove and finish silicone or caulking to desired look.
- Handling marks or residue on the finished edges can be removed by using a Scotch-Brite™ Finishing Pad 7445 or 7448.

Care and Maintenance—Wilsonart[®] THINSCAPE[®] Performance Tops

Everyday cleaning of this product is as simple as a quick wipe with a damp sponge, as it is resistant to muddy fingerprints, toothpaste spills, and so much more. To clean the surface, use a damp cloth or sponge and a mild soap or detergent. Rinse thoroughly with warm water, and wipe dry. Difficult stains can be removed using a mild household cleaner/detergent and a soft bristled brush, repeating as necessary. Please visit www.wilsonart.com/thinscape for complete Care & Maintenance instructions, including approved cleaners.

Recommended Household Cleaners

Windex[®] Glass Plus[®] Fantastik[®] Mr. Clean[®] Formula 409[®] Isopropyl Alcohol (Isopropanol)

NOTE: Prolonged exposure to bleach will cause discoloration. Do not use toilet bowl cleaners or other abrasive cleaners.

Care and Maintenance—Installed Porcelain Sink

Daily care and cleaning with a soft cloth will keep your sink looking its best. Use non-abrasive cleaners for regular care. Do not use abrasive scouring pads or brushes. Harsh abrasive cleaners and pads can damage the surface and finish of the porcelain. Do not allow items that may stain the porcelain to be in contact with the surface for extended periods of time. Avoid using hair or clothing dyes in the sink. Also take precautions that nail polish does not come in contact with the surface.

For additional information, questions, or technical assistance, please contact our Wilsonart Smartline at 800.433.3222 or smartline@wilsonart.com, Monday through Friday, 8am - 5pm, CST.